SUN2000MA

V100R001

MODBUS Interface Definitions

Issue 01

Date 2020-06-20

HUAWEI TECHNOLOGIES CO., LTD.

Copyright © Huawei Technologies Co., Ltd. 2020. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.
All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: https://e.huawei.com

Contents

1 Introduction ... 1
1.1 Terms and Abbreviations ... 1
1.2 System Requirements ... 2
1.3 Inverter Models and Rated Power ... 2
2 Register Definitions ... 4
3 Alarms ... 15
4 Definition of Optimizer Data ... 17
4.1 Real-time Data ... 17
4.2 Feature Data ... 20
5 Communication Protocol Overview ... 22
5.1 Physical Layer ... 22
5.2 Data Link Layer ... 22
5.2.1 Addressing Mode ... 22
5.2.2 Frame Structure ... 22
5.2.3 Data Encoding ... 23
5.2.4 Interaction Process ... 24
5.3 Application Layer ... 24
5.3.1 Function Code List ... 24
5.3.2 File Type Code List ... 24
5.3.3 Exception Code List ... 24
5.3.4 Reading Registers (0X03) ... 27
5.3.4.1 Frame Format for a Request from a Master Node ... 27
5.3.4.2 Frame Format for a Normal Response from a Slave Node ... 28
5.3.4.3 Frame Format for an Abnormal Response from a Slave Node ... 28
5.3.4.4 Example ... 28
5.3.5 Writing a Single Register (0X06) ... 30
5.3.5.1 Frame Format for a Request from a Master Node ... 30
5.3.5.2 Frame Format for a Normal Response from a Slave Node ... 30
5.3.5.3 Frame Format for an Abnormal Response from a Slave Node ... 30
5.3.5.4 Example ... 30
5.3.6 Writing Multiple Registers(0X10) ... 32
5.3.6.1 Frame Format for a Request from a Master Node ... 32

 Copyright © Huawei Technologies Co., Ltd.

5.3.6.2 Frame Format for a Normal Response from a Slave Node....32
5.3.6.3 Frame Format for an Abnormal Response from a Slave Node....33
5.3.6.4 Example....33
5.3.7 Reading Device Identifiers (0X2B)....34
5.3.7.1 Commands for Querying Device Identifiers....35
5.3.7.2 Command for Querying a Device List....36
5.3.7.3 Device Description Definitions....38
5.3.8 Uploading Files....39
5.3.8.1 Upload Process....39
5.3.8.2 Starting the Upload....40
5.3.8.3 Uploading Data....42
5.3.8.4 Completing the Data Upload....43
5.3.8.5 Timeout Processing....43

1 Introduction

1.1 Terms and Abbreviations

Table 1-1 Terms and Abbreviations

Name	Description
Master node	During master-slave communication, the party that initiates a communication request is referred to as the master node.
Slave node	During master-slave communication, the party that responds to a communication request is referred to as the slave node.
Broadcast address	Fixed to 0.
Register address	The address of a register is recorded in two bytes.
U16	Unsigned integer (16 bits)
U32	Unsigned integer (32 bits)
I16	Signed integer (16 bits)
I32	Signed integer (32 bits)
STR	String
MLD	Multiple bytes
N/A	Not applicable
s	Second
Epoch seconds	The number of seconds that have elapsed since 1970-01-01 00: 00: 00

 Copyright © Huawei Technologies Co., Ltd.

1.2 System Requirements

Software version: V100R001C00 or later

1.3 Inverter Models and Rated Power

Table 1-2 Rated inverter capacity

Model ID	Model Name
400	SUN2000-5KTL-M0
401	SUN2000-5KTL-M0
402	SUN2000-6KTL-M0
403	SUN2000-6KTL-M0
404	SUN2000-8KTL-M0
405	SUN2000-8KTL-M0
406	SUN2000-10KTL-M0
407	SUN2000-10KTL-M0
408	SUN2000-12KTL-M0
410	SUN2000-3KTL-M0
411	SUN2000-4KTL-M0
412	SUN2000-15KTL-M0
413	SUN2000-17KTL-M0
414	SUN2000-20KTL-M0
415	SUN2000-8KTL
416	SUN2000-10KTL
417	SUN2000-12KTL
418	SUN2000-8KTL-M0
419	SUN2000-10KTL-M0
420	SUN2000-12KTL-M0
421	SUN2000-15KTL-M0
422	SUN2000-17KTL-M0
423	SUN2000-20KTL-M0
424	SUN2000-3KTL-M1

 Copyright © Huawei Technologies Co., Ltd.

Model ID	Model Name
425	SUN2000-4KTL-M1
426	SUN2000-5KTL-M1
427	SUN2000-6KTL-M1
428	SUN2000-8KTL-M1
429	SUN2000-10KTL-M1
430	SUN2000-8KTL-M2
431	SUN2000-10KTL-M2
432	SUN2000-12KTL-M2
433	SUN2000-15KTL-M2
434	SUN2000-17KTL-M2
435	SUN2000-20KTL-M2

NOTE

The maximum active power (Pmax), maximum reactive power (Qmax), and rated power (Pn) corresponding to each model can be obtained through the register interface.

 Copyright © Huawei Technologies Co., Ltd.

2 Register Definitions

Table 2-1 Register Definitions

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
1	Model Name	RO	STR	N/A	1	30000	15	**1.3 Inverter Models and Rated Power**
2	SN	RO	STR	N/A	1	30015	10	
3	PN	RO	STR	N/A	1	30025	10	
4	Model ID	RO	U16	N/A	1	30070	1	**1.3 Inverter Models and Rated Power**
5	String Number	RO	U16	N/A	1	30071	1	
6	MPPT Number	RO	U16	N/A	1	30072	1	
7	Rated power (Pn)	RO	U32	kW	1000	30073	2	
8	Maximum active power (Pmax)	RO	U32	kW	1000	30075	2	
9	Maximum apparent power (Smax)	RO	U32	kVA	1000	30077	2	

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
10	Maximum reactive power (Qmax, fed to the power grid)	RO	I32	kVar	1000	30079	2	
11	Maximum reactive power (Qmax, absorbed from the power grid)	RO	I32	kVar	1000	30081	2	
12	Standalone teleindication	RO	U16	N/A	1	32000	1	Bit 0: standby Bit 1: grid connection Bit 2: normal grid connection Bit 3: grid connection with derating due to power rationing Bit 4: grid connection with derating due to inverter internal causes Bit 5: normal stop Bit 6: stop due to faults Bit 7: stop due to power rationing Bit 8: shutdown Bit 9: spot check

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
13	Operating status	RO	U16	N/A	1	32002	1	Bit 0: locking status (0: locked; 1: unlocked) Bit 1: PV connection status (0: disconnected; 1: connected) Bit 2: DSP data collection (0: no; 1: yes)
14	Alarm 1	RO	U16	N/A	1	32008	1	**3 Alarms**
15	Alarm 2	RO	U16	N/A	1	32009	1	**3 Alarms**
16	Alarm 3	RO	U16	N/A	1	32010	1	**3 Alarms**
17	PV1 Voltage	RO	I16	V	10	32016	1	
18	PV1 Current	RO	I16	A	100	32017	1	
19	PV2 Voltage	RO	I16	V	10	32018	1	
20	PV2 Current	RO	I16	A	100	32019	1	
21	PV3 Voltage	RO	I16	V	10	32020	1	
22	PV3 Current	RO	I16	A	100	32021	1	
23	PV4 Voltage	RO	I16	V	10	32022	1	
24	PV4 Current	RO	I16	A	100	32023	1	
25	Input power	RO	I32	kW	1000	32064	2	
26	Grid Voltage	RO	U16	V	10	32066	1	

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
27	Grid Current	RO	I32	A	1000	32072	2	
28	Active power peak of current day	RO	I32	kW	1000	32078	2	
29	Active power	RO	I32	kW	1000	32080	2	
30	Reactive power	RO	I32	kVar	1000	32082	2	
31	Power factor	RO	I16	N/A	1000	32084	1	
32	Frequency	RO	U16	Hz	100	32085	1	
33	Inverter efficiency	RO	U16	%	100	32086	1	
34	Cabinet temperature	RO	I16	℃	10	32087	1	
35	Insulation resistance	RO	U16	MΩ	1000	32088	1	

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
36	Device status	RO	U16	N/A	1	32089	1	0x0000:Idle: Initializing 0x0001:Idle: Detecting ISO 0x0002:Idle: Detecting irradiation 0x0003:Idle: Grid detecting 0x0100:Starting 0x0200:On-grid 0x0201:On-grid: Power limit 0x0202:On-grid:self derating 0x0300:Shutdown: Fault 0x0301:Shutdown: Command 0x0302:Shutdown: OVGR 0x0303:Shutdown: Communication disconnected 0x0304:Shutdown: Power limit 0x0305:Shutdown: Start manually 0x0306:Shutdown: DC switch OFF 0x0401:Grid dispatch: cos(Phi)-P curve 0x0402:Grid dispatch: Q-U curve 0xA000:Idle: No irradiation 0x0500:Spot-check

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
								0x0501:Spot-checking 0x0600:Inspecting 0X0700:AFCI self-check 0X0800:IV scanning 0X0900:DC input detection
37	Fault code	RO	U16	N/A	1	32090	1	
38	Startup time	RO	U32	N/A	1	32091	2	Epoch seconds, local time
39	Shutdown time	RO	U32	N/A	1	32093	2	Epoch seconds, local time
40	E-Total	RO	U32	kWh	100	32106	2	
41	E-Day	RO	U32	kWh	100	32114	2	
42	System Time	RW	U32	N/A	1	40000	2	[946684800, 3155759999] Epoch seconds, local time
43	(Energy storage device) Charge and discharge power	RO	I32	W	1	37001	2	>0: charge <0: discharge
44	(Energy storage device) Charge capacity on current day	RO	U32	kWh	100	37015	2	

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
45	(Energy storage device) Discharge capacity on current day	RO	U32	kWh	100	37017	2	
46	(Electric meter) Active power	RO	I32	W	1	37113	2	>0: feed power to the power grid <0: obtain power from the power grid
47	(Optimizer) Total number	RO	U16	N/A	1	37200	1	
48	(Optimizer) Number of online devices	RO	U16	N/A	1	37201	1	
49	(Optimizer) Feature data sequence number	RO	U16	N/A	1	37202	1	Synchronize the feature data files after the sequence numbers change.
50	Reactive power compensation (PF)	RW	I16	N/A	1000	40122	1	(-1,-0.8]U[0.8,1]
51	Reactive power compensation(Q/S)	RW	I16	N/A	1000	40123	1	(-1,1]
52	Active power derating percent(0.1%)	RW	U16	%	10	40125	1	[0,100]
53	Active power derating (fixed value W)	RW	U32	W	1	40126	2	[0,Pmax]

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
54	Power on	WO	U16	N/A	1	40200	1	
55	Power off	WO	U16	N/A	1	40201	1	
56	Time zone	RW	I16	min	1	43006	1	[-720,840]
57	(Energy storage device) Working mode	RW	UINT16	N/A	1	47004	1	0: unlimited 1: grid connection with zero power 2: on-grid with limited
58	(Energy storage device) Fixed charge and discharge time period	RW	MULTIDATA	N/A	1	47006	21	A maximum of 10 time periods can be set. Data header: (2 bytes) number of valid time periods Time period data: **Start time (uint16) + End time (unit16)** Time: minute as the unit, equals X hour X minute starting from 0 o'clock on the current day. Each field is transmitted in the high byte order.
59	(Energy storage device) Time-of-use electricity price	RW	UINT16	N/A	1	47027	1	0:Disable 1:Enable

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
60	(Energy storage device) Time-of-use electricity price time period	RW	MULTIDATA	N/A	1	47028	41	A maximum of 10 time periods can be set. Data header: (2 bytes) number of valid time periods Time period data: **Start time (uint16) + End time (unit16) + Electricity price (unit32)** Time: minute as the unit, equals X (hour) X (minute) starting from 0 o'clock on current day. Electricity price: no unit, amplification factor 1000. Each field is transmitted in the high byte order.
61	(Energy storage device) power cost per kWh	RW	UINT32	N/A	1000	47069	2	
62	(Energy storage device, charge and discharge curve) Maximum charge power	RW	UINT32	W	1	47075	2	[0, Min ("rated charge power," Pmax)] Default value: 3500

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
63	(Energy storage device, charge and discharge curve) Maximum discharge power	RW	UINT32	W	1	47077	2	[0, Min ("rated discharge power," Pmax)] Default value: 3500
64	(Energy storage device) Grid-tied point power limitation	RW	INT32	W	1	47079	2	[0, Pmax] Default value: Pmax
65	(Energy storage device) Full charge capacity	RW	UINT16	%	10	47081	1	[90,100] Default value:100
66	(Energy storage device) Full discharge capacity	RW	UINT16	%	10	47082	1	[12,20] Default value:15
67	(Energy storage device) Forced charge and discharge period	RW	UINT16	mins	1	47083	1	[0,1440] Not stored

 Copyright © Huawei Technologies Co., Ltd.

SN	Signal Name	Read / Write	Type	Unit	Gain	Address	Quantity	Scope
68	(Energy storage device) Forced charge and discharge power	RW	INT32	W	1	47084	2	[-"Maximum discharge power," "Maximum charge power"] Forced charge and discharge power ≤ Maximum charge and discharge power ≤ Rated charge and discharge power Not stored

3 Alarms

Table 3-1 Alarms List

SN	Alarm	Bit	Alarm Name	Alarm ID	Severity
1	Alarm 1	0	High String Voltage	2001	Major
2	Alarm 1	1	DC Arc Fault	2002	Major
3	Alarm 1	2	String Reversed	2011	Major
4	Alarm 1	3	PV String Backfeed	2012	Warning
5	Alarm 1	4	Abnormal String	2013	Warning
6	Alarm 1	5	AFCI Self-test Fault	2021	Major
7	Alarm 1	6	Short circuit between phase to PE	2031	Major
8	Alarm 1	7	Power Grid Failure	2032	Major
9	Alarm 1	8	Grid Undervoltage	2033	Major
10	Alarm 1	9	Grid Overvoltage	2034	Major
11	Alarm 1	10	Unbalanced Grid Voltage	2035	Major
12	Alarm 1	11	Grid Overfrequency	2036	Major
13	Alarm 1	12	Grid Underfrequency	2037	Major
14	Alarm 1	13	Grid Frequency Instability	2038	Major
15	Alarm 1	14	Output Overcurrent	2039	Major
16	Alarm 1	15	Large DC of Output current	2040	Major
17	Alarm 2	0	Abnormal Leakage Current	2051	Major
18	Alarm 2	1	Abnormal Ground.	2061	Major
19	Alarm 2	2	Low Insulation Res.	2062	Major

 Copyright © Huawei Technologies Co., Ltd.

SN	Alarm	Bit	Alarm Name	Alarm ID	Severity
20	Alarm 2	3	High Temperature	2063	Major
21	Alarm 2	4	Abnormal Equipment	2064	Major
22	Alarm 2	5	Upgrade Failed	2065	Minor
23	Alarm 2	6	License Expired	2066	Warning
24	Alarm 2	7	Abnormal Monitor Unit	61440	Minor
25	Alarm 2	8	Power collector fault	2067	Major
26	Alarm 2	9	Abnormal energy storage device	2068	Minor
27	Alarm 2	10	Active islanding	2070	Major
28	Alarm 2	11	Passive islanding	2071	Major
29	Alarm 2	12	Transient AC overvoltage	2072	Major
30	Alarm 2	13	External device port short circuit	2075	Warning
31	Alarm 2	14	Off-grid output overload	2077	Major
32	Alarm 2	15	Abnormal PV module configuration	2080	Major
33	Alarm 3	0	Optimizer fault	2081	Warning

 Copyright © Huawei Technologies Co., Ltd.

4 Definition of Optimizer Data

4.1 Real-time Data

Data synchronization mechanism: five-minute interval

Synchronization process: uploads the files and synchronizes data according to the time period; uploads the most recent data if there is no filter condition.

Storage: stores real-time data at five-minute intervals.

Table 4-1 File format

Data	Length (Bytes)	Remarks
File version	4	V101
Reserved	8	
Optimized data unit 1	N	12 + 26 x Number of optimizers , For details about the definition of this unit, see the data unit format.
Optimized data unit 2	N	
Optimized data unit...	N	
Optimized data unit N	N	N indicates the number of data records that are filtered out. Each piece of data contains all optimizer data of a time node.

 Copyright © Huawei Technologies Co., Ltd.

Table 4-2 Data unit format

Data	Length (Bytes)	Remarks
Time	4	Epoch second, local time
Reserved	4	
Length	2	
Number of optimizers	2	
Real-time data of optimizer 1	26	For details about the definition of this unit, see the real-time data format.
Real-time data of optimizer 2	26	
Real-time data of optimizer...		
Real-time data of optimizer N	26	N indicates the number of optimizers.

Table 4-3 Real-time data format

Data	Length (Bytes)	Remarks
Optimizer address	2	Logical communication address
Output power	2	Amplification factor: 10 Unit: W
Voltage to ground	2	Amplification factor: 10 Unit: V

 Copyright © Huawei Technologies Co., Ltd.

Data	Length (Bytes)	Remarks
Fault alarm	4	Bit00: input overvoltage Bit01: input undervoltage Bit02: output overvoltage Bit04: overtemperature Bit06: output short circuit Bit07: EEPROM fault Bit08: internal hardware fault Bit09: abnormal voltage to ground Bit 10: power-off due to heartbeat timeout Bit 11: fast shutdown Bit 12: request escape alarm Bit 13: version mismatch alarm Bit 16: input overvoltage Bit 17: overtemperature Bit 18: output short circuit Bit 19: internal hardware fault Bit 20: version mismatch alarm Bit 21: backfeed alarm Bit 22: abnormal output voltage Bit 23: upgrade failure Bit 31: alarm display selection, 1=Display bit 16 to bit 30 alarms, 0: Bits 0 to 15 are displayed.
Output voltage	2	Amplification factor: 10 Unit: V
Output current	2	Amplification factor: 100 Unit: A
Input voltage	2	Amplification factor: 10 Unit: V
Input current	2	Amplification factor: 100 Unit: A
Temperature	2	Amplification factor: 10 Unit: °C

 Copyright © Huawei Technologies Co., Ltd.

Data	Length (Bytes)	Remarks
Operating status	2	0: offline 1: standby 3: faulty 4: running 12: power-off
Total energy yield	4	Amplification factor: 1000 Unit: kWh

4.2 Feature Data

Data synchronization mechanism: updates feature data files by the feature sequence numbers of optimizers.

Synchronization process: uploads the files and fully synchronizes them.

Inverter storage: updates the file after the optimizer finishes locating the position.

Table 4-4 File format

Data	Length (Bytes)	Remarks
File version	4	V102
Feature data sequence number	2	
Length	2	
Reserved	1	The reserved byte 0 is defined as the status. bit0: inverter disconnection status (1=disconnected)
	3	
Number of optimizers	2	Total number, including the offline optimizers.
Feature data of optimizer 1	108	For details about the data domain definition, see the Optimizer Feature Data Domain Definition.
Feature data of optimizer 2	108	

 Copyright © Huawei Technologies Co., Ltd.

Data	Length (Bytes)	Remarks
Feature data of optimizer...	108	
Feature data of optimizer N	108	

Table 4-5 Feature data unit format

Data	Length (Bytes)	Remarks
Optimizer address	2	RS485 address
Online status	2	0: offline 1: online 2: disconnected
String number	2	
Position in current string	2	relative positive connection starting point
SN	20	
Software version	30	
Alias	20	
Model	30	

 Copyright © Huawei Technologies Co., Ltd.

5 Communication Protocol Overview

5.1 Physical Layer

Communicates over an Ethernet.

5.2 Data Link Layer

5.2.1 Addressing Mode

NOTE

The address of device is 0.

5.2.2 Frame Structure

Data Field	Length	Description
MBAP Header	7 byte	Table 5-1
Function Code	1 byte	NA
Data	N byte	NA

WARNING

A ModBus-TCP frame can contain a maximum of 256 bytes.

The following table describes the format of an MBAP header:

 Copyright © Huawei Technologies Co., Ltd.

Table 5-1 MBAP Definitions

Data Field	Length (Bytes)	Description	Master Node	Slave Node
Transmission identifier	2	Matching identifier between a request frame and a response frames	Assigned by the master node; better be unique for each data frame.	The identifier of the response frame from the slave node must be consistent with that of the request frame.
Protocol type	2	0 = Modbus protocol	Assigned by the master node; 0 by default.	The identifier of the response frame from the slave node must be consistent with that of the request frame.
Data length	2	Follow-up data length	Assigned by the master node based on the actual data frame.	Assigned by the slave node based on the actual frame length.
Logic device ID	1	0	Assigned by the master node based on the actual data frame request.	The identifier of the response frame from the slave node must be consistent with that of the request frame.

5.2.3 Data Encoding

Modbus uses a big-Endian to represent addresses and data. When multiple bytes are sent, the payload digit leftmost is sent first.

Example:

 Copyright © Huawei Technologies Co., Ltd.

Register Size	Value
16 bits	0x1234

The system sends 0x12, and then sends 0x34.

5.2.4 Interaction Process

A communication process is always initiated by a master node. Slave nodes do not initiate communication processes.

A slave node returns one response for each request from the master node. If the master node does not receive any response from the slave node in 5s, the communication process is regarded as timed out.

5.3 Application Layer

5.3.1 Function Code List

Table 5-2 Function code list

Function Code	Meaning	Remarks
0x03	Read registers.	Supports continuous reading of single or multiple registers.
0x06	Write a single register.	Supports writing into a single register.
0x10	Write multiple registers.	Supports continuous writing into multiple registers.

5.3.2 File Type Code List

File Type	Meaning
0X44	Real-time Data of Optimizer
0X45	Feature Data of Optimizer

5.3.3 Exception Code List

The exception codes must be unique for each NE type. The names and descriptions are provided in the NE interface document. Different versions of the

same NE type must be backward compatible. Exception codes in use cannot be assigned to other exceptions.

Table 5-3 Table of exception codes returned by an NE (0x00–0x8F are for common exception codes)

Code	Name	Meaning
0x01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server. This may be because the function code is only applicable to newer devices, and was not implemented in the unit selected. It could also indicate that the server is in the wrong state to process a request of this type, for example because it is unconfigured and is being asked to return register values.

 Copyright © Huawei Technologies Co., Ltd.

Code	Name	Meaning
0x02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server. More specifically, the combination of reference number and transfer length is invalid. For a controller with 100 registers, the PDU addresses the first register as 0, and the last one as 99. If a request is submitted with a starting register address of 96 and a quantity of registers of 4, then this request will successfully operate (address-wise at least) on registers 96, 97, 98, 99. If a request is submitted with a starting register address of 96 and a quantity of registers of 5, then this request will fail with Exception Code 0x02 "Illegal Data Address" since it attempts to perform operations on registers 96, 97, 98, 99 and 100, and there is no register with address 100.

 Copyright © Huawei Technologies Co., Ltd.

Code	Name	Meaning
0x03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for server. This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does not mean that a data item submitted for storage in a register has a value outside the expectation of the application program, since the Modbus protocol is unaware of the significance of any particular value of any particular register.
0x04	SERVER DEVICE FAILURE	An unrecoverable error occurred while the server was attempting to perform the requested action.
0x06	SERVER DEVICE BUSY	The server does not accept a ModBus request PDU. A client application determines when to resend the request.
0x80	NO PERMISSION	An operation is not allowed because of a permission authentication failure or permission expiration.

5.3.4 Reading Registers (0X03)

5.3.4.1 Frame Format for a Request from a Master Node

Data Field	Length	Description
Function code	1 byte	0x03
Register start address	2 byte	0x0000–0xFFFF

 Copyright © Huawei Technologies Co., Ltd.

Data Field	Length	Description
Number of registers	2 byte	1–125

5.3.4.2 Frame Format for a Normal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x03
Number of bytes	1 byte	2×N
Register value	2xN byte	NA

NOTE

N indicates the number of registers.

5.3.4.3 Frame Format for an Abnormal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x83
Exception code	1 byte	See the Exception Code List

5.3.4.4 Example

A master node sends a request to a slave node (logic device ID: 00) to query register whose address is 32306/0X7E32. The request frame format is as follows:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		06
	Logic Device ID	00
Function Code		03

Description		Frame data
Data	Register Address	7E
		32
	Number of Registers	00
		02

Frame format of a normal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		07
	Logic Device ID	00
Function Code		03
Data	Number of bytes	04
	RegisterValue	00
		00
		00
		01

Frame format of an abnormal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		03

 Copyright © Huawei Technologies Co., Ltd.

Description		Frame data
	Logic Device ID	00
Function Code		83
Data	Error Code	03

5.3.5 Writing a Single Register (0X06)

5.3.5.1 Frame Format for a Request from a Master Node

Data Field	Length	Description
Function code	1 byte	0x06
Register Address	2 bytes	0x0000–0xFFFF
Register Value	2 bytes	0x0000–0xFFFF

5.3.5.2 Frame Format for a Normal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x06
Register Address	2 bytes	0x0000–0xFFFF
Register Value	2 bytes	0x0000–0xFFFF

5.3.5.3 Frame Format for an Abnormal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x86
Exception code	1 byte	See the Exception Code List

5.3.5.4 Example

A master node sends instruction(register address: 40200/0X9D08) to a slave node whose address is 00. The request frame format is as follows:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		06
	Logic Device ID	00
Function Code		06
Data	Register Address	9D
		08
	Register Value	00
		00

Frame format of a normal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		06
	Logic Device ID	00
Function Code		06
Data	Register Address	9D
		08
	Register Value	00
		00

Frame format of an abnormal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		03
	Logic Device ID	00
Function Code		86
Data	Error Code	04

5.3.6 Writing Multiple Registers(0X10)

5.3.6.1 Frame Format for a Request from a Master Node

Data Field	Length	Description
Function code	1 byte	0x10
Register start address	2 byte	0x0000–0xFFFF
Number of registers	2 byte	0x0000–0x007b
Number of bytes	1 byte	2×N
Register value	2×N byte	Value

NOTE

N indicates the number of registers.

5.3.6.2 Frame Format for a Normal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x10
Register address	2 bytes	0x0000–0xFFFF
Number of registers	2 bytes	0x0000–0x007b

 Copyright © Huawei Technologies Co., Ltd.

5.3.6.3 Frame Format for an Abnormal Response from a Slave Node

Data Field	Length	Description
Function code	1 byte	0x90
Exception code	1 byte	See the Exception Code List

5.3.6.4 Example

A master node sends an instruction to a slave node whose address is 00 to set (register address: 40118/0X9CB6) to 2, and set (register address: 40119/0X9CB7) to 50. The request frame format is as follows:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		0B
	Logic device ID	00
Function Code		10
Data	Register Address	9C
		B6
	Number of Registers	00
		02
	Number of Bytes	04
	Register Value	00
		02
		00
		32

Frame format of a normal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		06
	Logic device ID	00
Function Code		10
Data	Register Address	9C
		B6
	Number of Registers	00
		02

Frame format of an abnormal response from the slave node:

Description		Frame data
MBAP Header	Protocol Identifier	00
		01
	Protocol Type	00
		00
	Data Length	00
		03
	Logic Device ID	00
Function Code		90
Data	Error Code	04

5.3.7 Reading Device Identifiers (0X2B)

This command code allows reading identifiers and added packets that are relevant to the physical and function description of the remote devices.

Simulate the port of the read device identifier as an address space. This address space consists of a set of addressable data elements. The data elements are objects to be read, and the object IDs determine these data elements.

 Copyright © Huawei Technologies Co., Ltd.

A data element consists of three objects:

- Basic device identifier: All objects of this type are mandatory, such as the manufacturer name, product code, and revision version.
- Normal device identifier:Except the basic data objects, the device provides additional and optional identifiers and data object description. Normal device identifiers define all types of objects according to standard definitions, but the execution of this type of objects is optional.
- Extensive device identifier:Except the basic data objects, the device provides additional and optional identifiers and special data object description. All these data objects are related to the device.

Table 5-4 Reading Device Identifiers

Object ID	Object Name or Description	Type	M/O	Category
0x00	Manufacturer name	ASCII character string	M	Basic
0x01	Product code	ASCII character string	M	
0x02	Main revision	ASCII character string	M	
0x03–0x7F	--	--	--	Normal
0x80–0xFF	--	--	--	Extensive

5.3.7.1 Commands for Querying Device Identifiers

Table 5-5 Request frame format

Data Field	Length (Byte)	Description
Function code	1	0x2B
MEI type	1	0x0E
ReadDevId code	1	01
Object ID	1	0x00

Table 5-6 Frame format for a normal response

Data Field	Length (Byte)	Description
Function code	1	0x2B
MEI type	1	0x0E
ReadDevId code	1	01

 Copyright © Huawei Technologies Co., Ltd.

Data Field			Length (Byte)	Description
Consistency level			1	01
More			1	N/A
Next object ID			1	N/A
Number of objects			1	N/A
Object list	First object	Object ID	1	0x00
		Object length	1	N
		Object value	N	N/A
	...	...	...	...

Table 5-7 Object list

Object ID	Object Name or Description	Description	Category
0x00	Manufacturer name	HUAWEI	Basic
0x01	Product code	SUN2000	
0x02	Main revision	ASCII character string, software version	

Table 5-8 Frame format for an abnormal response

Data Field	Length (Byte)	Description
Function code	1	0xAB
Exception code	1	See **Exception Code List**

5.3.7.2 Command for Querying a Device List

Table 5-9 Request frame format

Data Field	Length (Byte)	Description
Function code	1	0x2B
MEI type	1	0x0E

Data Field	Length (Byte)	Description
ReadDevId code	1	03
Object ID	1	0x87

Table 5-10 Frame format for a normal response

Data Field			Length (Byte)	Description
Function code			1	0x2B
MEI type			1	0x0E
ReadDevId code			1	03
Consistency level			1	03
More			1	N/A
Next object ID			1	N/A
Number of objects			1	N/A
Object list	First object	Object ID	1	0x87
		Object length	1	N
		Object value	N	N/A
	...	...	...	...

Table 5-11 Object list

Object ID	Object Name	Type	Description
0x80-0x86	Reserved		Returns a null object with a length of 0.
0x87	Number of devices	int	Returns the number of devices connected to the RS485 address.

 Copyright © Huawei Technologies Co., Ltd.

Object ID	Object Name	Type	Description
0x88	Information about the first device	ASCII character string See the device description definitions below.	Returns information only for the first device if a network element allows only one device to be connected to each RS485 address.
0x8A	Information about the second device	N/A	N/A
.....	.....	.....	.....
0xFF	Information about the 120th device	N/A	N/A

5.3.7.3 Device Description Definitions

Each device description consists of all"attribute = value" strings.

Attribute label=%s;attribute label=%s;...attribute label=%s

For example:1=SUN2000L-XXKTL;2=V100R001C00SPC100;3=P1.0-D5.0;4=123232323;5=1;6=1.1

Table 5-12 Attribute definitions

Attribute Label	Attribute Name	Type	Description
1	Device Model	ASCII character string	SUN2000
2	Software version	ASCII character string	N/A
3	Version of the communications protocol	ASCII character string	See the interface protocol version definitions.
4	ESN	ASCII character string	N/A
5	Device number	int	0,1,2,3...(Assigned by NE; 0 indicates the master device to which the ModBus card is inserted)

 Copyright © Huawei Technologies Co., Ltd.

Attribute Label	Attribute Name	Type	Description
6	Character version	ASCII character string	N/A

Table 5-13 Frame format for an abnormal response

Data Field	Length (Byte)	Description
Function code	1	0xAB
Exception code	1	See **Exception Code List**

5.3.8 Uploading Files

5.3.8.1 Upload Process

Uploading a file means uploading it from a slave node to a master node. The following figure shows the file uploading process.

Figure 5-1 File upload process



5.3.8.2 Starting the Upload

Table 5-14 Frame format of a request from a master node

Data Field		Length	Specifications
Function code		1 byte	0x41
Sub-function code		1 byte	0x05
Data length		1 byte	File type (1 byte) + User-defined data (N bytes)
File type		1 byte	See section 5.3.2 "File Type Code."
User-defined data	Tag	1 byte	0X10 (query by the time period)
	Size	1 byte	12

Data Field		Length	Specifications
	Start time	4 bytes	Epoch seconds, 0xFFFFFFFF indicating the invalid time or the start time that is not filtered
	End time	4 bytes	Epoch seconds, 0xFFFFFFFF indicating the invalid time or the end time that is not filtered
	Querying the maximum number of records	4 bytes	The maximum number of records N on the inverter. 0 indicates invalid condition, and the inverter uploads all the records that meet the time requirements.

Table 5-15 Frame format of a normal response from a slave node

Data Field	Length	Specifications
Function code	1 byte	0x41
Sub-function code	1 byte	0x05
Data length	1 byte	0x06 + N
File type	1 byte	See section 5.3.2 "File Type Code."
File length	4 bytes	
Data frame length	1 byte	
Single record length	4 bytes	

Table 5-16 Frame format of an abnormal response from a slave node

Data Field	Length	Specifications
Error code	1 byte	0xC1

Data Field	Length	Specifications
Exception code	1 byte	See the Exception Code List.

NOTE

If the exception code is 0x06, the request will be resent after 10 seconds. The request can be resent for no more than six times.

5.3.8.3 Uploading Data

Table 5-17 Frame format of a request from a master node

Data Field	Length	Specifications
Function code	1 byte	0x41
Sub-function code	1 byte	0x06
Data length	1 byte	0x03
File type	1 byte	See section 5.3.2 "File Type Code."
Frame SN	2 bytes	0x0000–0xFFFF

Table 5-18 Frame format of a normal response from a slave node

Data Field	Length	Specifications
Function code	1 byte	0x41
Sub-function code	1 byte	0x06
Data length	1 byte	0x03 + N
File type	1 byte	See section 5.3.2 "File Type Code."
Frame SN	2 bytes	0x0000–0xFFFF
Frame data	N bytes	

Table 5-19 Frame format of an abnormal response from a slave node

Data Field	Length	Specifications
Error code	1 byte	0xC1
Exception code	1 byte	See the Exception Code List.

 Copyright © Huawei Technologies Co., Ltd.

5.3.8.4 Completing the Data Upload

Table 5-20 Frame format of a request from a master node

Data Field	Length	Specifications
Function code	1 byte	0x41
Sub-function code	1 byte	0x0c
Data length	1 byte	0x01 Indicates the file type (1 byte).
File type	1 byte	See section 5.3.2 "File Type Code."

Table 5-21 Frame format of a normal response from a slave node

Data Field	Length	Specifications
Function code	1 byte	0x41
Sub-function code	1 byte	0x0c
Data length	1 byte	0x03 File type (1 byte) + file CRC (2 bytes)
File type	1 byte	See section 5.3.2 "File Type Code."
File CRC	2 bytes	

Table 5-22 Frame format of an abnormal response from a slave node

Data Field	Length	Specifications
Error code	1 byte	0xC1
Exception code	1 byte	See the Exception Code List.

5.3.8.5 Timeout Processing

Table 5-23 Processing specifications of sub-process timeout

Item	Constraint
Response timeout period for starting an upload	10s
Response timeout period for uploading data	10s
Time of resending an data upload order	6

 Copyright © Huawei Technologies Co., Ltd.

Item	Constraint
Response timeout period for completing a data upload	10s